


Instant Pot Quick Reference Guide



READ USER GUIDE BEFORE USE

Key Sequences

Normal Sequences (Default)

Display shows Idle, Heating, Pressure-holding and Keep Warm.

With Options

Pre-Defined Function Key	Option Key (Step 1)	Option Key (Step 2)	Display
Soup/Congee/Stew/Bean	Adjust		Shorter/Normal/Longer light on
	Timer	+ or -	Delay time shown in hours
Rice/Multigrain	Timer	+ or -	Delay time shown in hours
Steam/Manual/Slow Cook	+ or -		Pressure-holding time shown in minutes
Keep Warm/Cancel	Adjust		Shorter/Normal/Longer light on

Instant Pot Company

Address: 11 - 300 Earl Grey Dr., Suite 383
Ottawa, Ontario
Canada K2T 1C1

Telephone: 1 800 828-7280
Web: <http://www.instantpot.com>
eMail: inquire@instantpot.com